

Desoutter

**Auto Feed Drills
and Tappers**

| Types | Code |
|-------------|--------|
| AFD40-23000 | 111164 |
| AFD40-10000 | 108194 |
| AFD40- 5300 | 115144 |
| AFD40- 3800 | 113104 |
| AFD40- 3000 | 112134 |
| AFD40- 1700 | 110194 |
| AFD40- 1200 | 109164 |
| AFD40- 800 | 116114 |
| AFD40- 500 | 114174 |
| AFT40- 1200 | 117184 |
| AFT40- 800 | 119124 |
| AFT40- 500 | 118154 |


Desoutter



Desoutter Limited,
319 Edgware Road, Colindale, London NW9 6ND,
Telephone: 01-205 7050 Telex: 21392

Printed in England

441



**Operating Instruc
Servicing Instruc
Parts List**



AFT40


AFT40

Parts List - Main Assembly

| Item No. | Part No. | Description | Qty. |
|----------|-----------|-----------------------------|------|
| 1 | 54223 | Thread Protecting Cap | 1 |
| 2 | 49333 | Bearing Sleeve | 1 |
| 3 | 53263 | Silencer Ring | 1 |
| 4 | 50093 | Outer Case | 1 |
| 5 | See later | Motor and Gearbox Complete | 1 |
| Section | | | |
| 6 | 49483 | Return Spring | 1 |
| 7 | 260813 | Spring Pin 3mm dia x 6mm lg | 2 |
| 8 | 257403 | Felt Wiper Ring | 1 |
| 9 | 37223 | O-Ring | 2 |
| 10 | 154263 | Clamp Ring | 1 |
| 11 | 257383 | Piston Seal | 1 |
| 12 | 265023 | Clamp Nut | 1 |
| 13 | 50783 | O-Ring | 1 |
| 14 | 265783 | Adaptor | 1 |
| 15 | 225553 | O-Ring | 1 |
| 16 | See later | Control Top Complete | 1 |
| Section | | | |
| 17 | 62542 | Male Stud Elbow | 1 |
| 18 | 60923 | Stroke Adjusting Screw | 1 |
| 19 | 52473 | Locknut | 3 |
| 20 | 254983 | Crosshead | 1 |
| 21 | 260823 | Air Feed Tube | 1 |
| 22 | 56053 | Screw | 1 |
| 23 | 51933 | Adjusting Screw | 1 |

* Indicates normal replacement items. It is recommended that adequate stocks are held for servicing requirements.

Always quote tool number, serial number and spare part number when ordering spares.



AFD40
AFT40

Parts List - Motor & Gearbox


| Item No. | Part No. | Description | Qty. |
|----------|-----------|---|------|
| 201 | 265243 | Clamp Nut | 1 |
| 202 | 265233 | Spindle Nut | 1 |
| 203 | 2413 | Bearing | 2 |
| 204 | 49023 | Washer | 1 |
| 205 | 2633 | Washer | 1 |
| 206 | See later | Gear Assemblies | |
| 207 | 254893 | Front Bearing Housing | 1 |
| *208 | 256123 | Spring Pin | 2 |
| *209 | 33433 | Bearing | 2 |
| 210 | 254873 | Bearing Plate | 2 |
| 211 | 254853 | Cylinder | 1 |
| 212 | 257063 | Rotor, 7 teeth, 500, 3000 rpm | 1 |
| | 37163 | Rotor, 8 teeth, 800, 1700, 3800 rpm | 1 |
| | 98223 | Rotor, 6 teeth, 1200, 5300 rpm | 1 |
| | 268673 | Rotor, 6 teeth, Ext. long, 23,000 rpm | 1 |
| *213 | 266663 | Rotor 8 teeth, 10,000 rpm | 1 |
| 214 | 500193 | Rotor blade | 5 |
| 215 | 254913 | Rear Bearing Housing | 1 |
| 216 | 254903 | End Cap | 1 |
| | 252763 | Motor Assembly 7 teeth, 500, 3000 rpm | 1 |
| | 252803 | Motor Assembly 8 teeth, 800, 1700, 3800 rpm | 1 |
| | 252783 | Motor Assembly 12 teeth, 1200, 5300 rpm | 1 |
| | 268563 | Motor Assembly 6 teeth 23,000 rpm | 1 |
| | 266663 | Motor Assembly 8 teeth 10,000 rpm | 1 |
| 217 | 238853 | Motor Case | 1 |
| 218 | 255793 | Piston | 1 |
| 219 | 257273 | Motor and Gearbox Assembly, 23,000 rpm | 1 |
| | 273203 | Motor and Gearbox Assembly, 10,000 rpm | 1 |
| | 257293 | Motor and Gearbox Assembly, 5300 rpm | 1 |
| | 257303 | Motor and Gearbox Assembly, 3800 rpm | 1 |
| | 257313 | Motor and Gearbox Assembly, 3000 rpm | 1 |
| | 257323 | Motor and Gearbox Assembly, 1700 rpm | 1 |
| | 257333 | Motor and Gearbox Assembly, 1200 rpm | 1 |

| Item No. | Part No. | Description | Qty. |
|----------|----------|-------------|------|
|----------|----------|-------------|------|

| | | |
|--------|-------------------------------------|---|
| 257343 | Motor and Gearbox Assembly, 900 rpm | 1 |
| 257353 | Motor and Gearbox Assembly, 500 rpm | 1 |

* Indicates normal replacement items. It is recommended that adequate stocks are held for servicing requirements.

Always quote tool number, serial number and spare part number when ordering spares.



AFD40
AFT40


Parts List - Gearbox

AF
AF

| Item No. | Part No. | Description | Qty. |
|----------|----------|--|------|
| 301 | 201263 | Spacer, 1200 rpm only | 1 |
| | 49373 | Bearing Spacer, 3000, 3800, 5300 rpm | 1 |
| 302 | 25568 | Key | 1 |
| 303 | 49433 | Gear Ring, 500, 800 rpm | 2 |
| | 55763 | Gear Ring, 1200 rpm | 1 |
| 304 | 49443 | Planet Cage, 500 rpm | 1 |
| | 49423 | Planet Cage, 800 rpm | 1 |
| | 201243 | Planet Cage, 1200 rpm | 1 |
| 305 | 40363 | Planet Wheel, 500 rpm | 1 |
| | 36723 | Planet Wheel, 800 rpm | 1 |
| | 201253 | Planet Wheel, 1200 rpm | 1 |
| 306 | 80013 | Planet Pin | 1 |
| 307 | 49453 | Planet Cage Assembly, 500 rpm | 1 |
| | 49413 | Planet Cage Assembly, 800 rpm | 1 |
| | 201233 | Planet Cage Assembly, 1200 rpm | 1 |
| 308 | 2413 | Bearing | 2 |
| 309 | 37523 | Distance Washer, 1200 rpm only | 1 |
| 310 | 25568 | Key, 500, 800, 3000, 3800, 5300 rpm only | 2 |
| 311 | 150823 | Gear Ring, 500, 3000 rpm | 1 |
| | 51973 | Gear Ring, 800 rpm | 1 |
| | 36713 | Gear Ring, 1200 rpm | 1 |
| | 55763 | Gear Ring, 3800, 5300 rpm | 1 |
| 112 | 2423 | Bearing | 1 |
| 113 | 51723 | Distance Collar, 500 rpm | 1 |
| | 51693 | Distance Collar, 800 rpm | 1 |
| 114 | 25673 | Clevis, 1200 rpm only | 1 |
| 115 | 502093 | Needle Cage | 1 |
| 116 | 150813 | Planet Wheel, 500, 3000 rpm | 2 |
| | 36703 | Planet Wheel, 800, 3800 rpm | 2 |
| | 65383 | Planet Wheel, 1200, 5300 rpm | 2 |
| 117 | 52083 | Planet Cage, 500 rpm | 1 |
| | 52063 | Planet Cage, 800 rpm | 1 |
| | 83123 | Planet Cage, 1200 rpm | 1 |
| | 49473 | Planet Cage, 3000 rpm | 1 |
| | 49463 | Planet Cage, 3800 rpm | 1 |
| | 201293 | Planet Cage, 5300 rpm | 1 |
| 118 | 1453 | Planet Pin | 2 |
| 119 | 151583 | Planet Cage Assembly, 500 rpm | 1 |
| | 52053 | Planet Cage Assembly, 800 rpm | 1 |
| 120 | 78053 | Planet Cage Assembly, 1200 rpm | 1 |
| 121 | 150803 | Planet Cage Assembly, 3000 rpm | 1 |
| | 49073 | Planet Cage Assembly, 3800 rpm | 1 |
| | 201283 | Planet Cage Assembly, 5300 rpm | 1 |
| 122 | 65373 | Rotor Pinion, 1200, 5300 rpm only | 1 |

* Indicates normal replacement items. It is recommended that adequate stocks are held for servicing requirements.

Always quote tool number, serial number and spare part number when ordering spares.




AFD40
AFT40

Parts List - Gearbox

| Item No. | Part No. | Description | Qty. |
|----------|----------|---------------------------------|------|
| 401 | 68983 | Bearing Spacer, 23,000 rpm only | 1 |
| 402 | 68973 | Chuck Spindle | 1 |
| * 403 | 2413 | Bearing | 1 |
| * 404 | 25568 | Key, 1700 rpm only | 1 |
| 405 | 52003 | Internal Gear | 1 |
| 406 | 51993 | Planet Cage | 1 |
| * 407 | 502093 | Needle Cage | 2 |
| 408 | 36703 | Planet Wheel | 2 |
| 409 | 1453 | Planet Pin | 2 |
| 410 | 52033 | Roller Bearing | 2 |
| 411 | 51983 | Planet Cage Assembly | 1 |
| 412 | 277993 | Spacer | 1 |
| 413 | 277903 | Washer Front | 1 |
| 414 | 277883 | Intermediate Pinion | 1 |
| 415 | 251493 | Planet Pin | 3 |
| * 416 | 266643 | Needle Roller | 30 |
| 417 | 266543 | Planet Wheel | 2 |
| 418 | 266493 | Retaining Washer | 2 |
| 419 | 266573 | Planet Carrier | 1 |
| 420 | 500683 | Planet Pin | 3 |
| * 421 | 251663 | Bearing | 3 |
| 422 | 266513 | Planet Wheel | 3 |
| 423 | 266483 | Gear Ring | 1 |
| 424 | 266503 | Washer, Rear | 1 |
| 425 | 266700 | Chuck Spindle | 1 |
| * 426 | 50083 | Bearing Spacer | 1 |
| * 427 | 2413 | Bearing | 1 |
| 428 | 204223 | Distance Piece | 1 |
| 429 | 76203 | Thrust Washer, Front | 1 |
| 430 | 251493 | Planet Pin | 1 |
| 431 | 251663 | Cage Needle Roller | 3 |
| 432 | 266543 | Planet Wheel | 3 |
| 433 | 266493 | Pin Retaining Washer | 2 |
| 434 | 266573 | Double Planet Carrier | 1 |
| * 435 | 500683 | Planet Pin | 3 |
| * 436 | 266643 | Needle Roller | 30 |
| 437 | 266513 | Planet Wheel | 3 |
| 438 | 266483 | Gear Ring | 1 |
| 439 | 266503 | Washer, Rear | 1 |

* Indicates normal replacement items. It is recommended that adequate stocks are held for servicing requirements.

Always quote tool number, serial number and spare part number when ordering spares.




AFD4V
AFT40

Parts List - Control Top

| Item No. | Part No. | Description | Qty. |
|----------|----------|------------------------------------|------|
| *101 | 41523 | 'O' Ring | 2 |
| 102 | 255763 | Control Top with Bushes | 1 |
| 103 | 256903 | Control Panel | 1 |
| *104 | 40503 | 'O' Ring | 1 |
| 105 | 256973 | Return Valve | 6 |
| 106 | 256933 | Needle Valve | 1 |
| 107 | 39763 | Spring | 3 |
| *108 | 43563 | 'O' Ring | 2 |
| 109 | 202773 | Valve Spindle | 2 |
| 110 | 51793 | Valve Body | 2 |
| 111 | 202833 | Button - Red | 1 |
| 112 | 203763 | Stop Valve Complete | 1 |
| 113 | 256923 | Valve Body Shrouded | 1 |
| 114 | 202843 | Button - Green | 1 |
| 115 | 256913 | Start Valve Complete | 1 |
| 116 | 236993 | Plug | 2 |
| 117 | 42953 | Inlet Adaptor - 1/2 in. BSP | 1 |
| | 47133 | Inlet Adaptor - 1/2 in. NPT | 1 |
| | 257043 | Pressure Reducer 1/8 in. BSP | 1 |
| | 257053 | Pressure Reducer 1/8 in. NPT | 1 |
| *118 | 51873 | Plug | 1 |
| *119 | 40533 | 'O' Ring | 2 |
| 120 | 51743 | Valve Spindle Complete | 1 |
| 121 | 172013 | Valve Body | 1 |
| 122 | 172003 | Stroke Control Valve | 1 |
| 123 | 257003 | Valve Bush | 1 |
| *124 | 43463 | 'O' Ring | 1 |
| 125 | 202763 | Piston Control Valve | 4 |
| *126 | 41513 | 'O' Ring | 1 |
| 127 | 202863 | End Cap | 3 |
| | 256823 | Control Top Complete - 1/2 in. BSP | 1 |
| | 256833 | Control Top Complete - 1/2 in. NPT | 1 |

* Indicates normal replacement items. It is recommended that adequate stocks are held for servicing requirements.

Always quote tool number, serial number and spare part number when ordering spares.






FD40
FT40

Chuck and Tapping Head

AFL
AFL



AFD40
AFT40

Servicing Instructions/Parts List - Tapping Head

| Item No. | Part No. | Description | Qty. |
|----------|----------|---|----------|
| 501 | 205323 | Chuck Retaining Screw for speeds 1700 rpm, 2300 rpm, 3200 rpm, 4600 rpm | 1 |
| | 205313 | Chuck Retaining Screw for speeds 500 rpm, 700 rpm, 1000 rpm | 1 |
| 502 | 29202 | Chuck Key for speeds 500 rpm | 1 |
| | 29242 | Chuck Key for speeds 1700 rpm | 1 |
| 503 | 34332 | Chuck for speeds 500 rpm, 700 rpm, 1000 rpm | 1 |
| | 34752 | Chuck for speeds 1700 rpm, 2300 rpm, 3200 rpm, 4600 rpm | 1 |
| 504 | 31642 | Nut | 1 |
| 505 | 29472 | Coilet $\frac{1}{4}$ in. Capacity | 1 |
| | 29482 | Coilet $\frac{1}{2}$ in. Capacity | 1 |
| 506 | 31622 | Body $\frac{1}{4}$ in. Capacity | 1 |
| | 31632 | Body $\frac{1}{2}$ in. Capacity | 1 |
| 507 | 31672 | Jaw | 1 |
| 508 | 37832 | Tapping Chuck Assembly $\frac{1}{4}$ in. Capacity | 1 |
| | 37822 | Tapping Chuck Assembly $\frac{1}{2}$ in. Capacity | 1 |
| 509 | 79783 | Screw | 1 |
| 510 | 67003 | Screw | 3 |
| 511 | 62153 | Spring Housing | 1 |
| 512 | 62293 | Spring | 1 |
| 513 | 62143 | Thrust Race Housing | 1 |
| 514 | 68818 | Outer Race | 1 |
| 515 | 68828 | Case and Balls | 1 |
| 516 | 61553 | End Cap | 1 |
| 517 | 1443 | Wheel | 2 |
| 518 | 10763 | Screw | 2 |
| 519 | 1463 | Roller | 22 |
| 520 | 10763 | Pin | 2 |
| 521 | 65123 | End Cap Assembly | 1 |
| 522 | 10713 | Sun Pinion | 1 |
| 523 | 77753 | Chuck Spindle | 1 |
| 524 | 10703 | Reverse Internal Gear | 1 |
| 525 | 64888 | Screw | 1 |
| 526 | 55073 | Weather | 1 |
| 527 | 53033 | Driving Dog | 1 |
| 528 | 162773 | Shim 0.005 in. (0.12 mm) | As req'd |
| | 162783 | Shim 0.010 in. (0.25 mm) | As req'd |
| | 162793 | Shim 0.020 in. (0.50 mm) | As req'd |
| 529 | 53043 | Extension Case | 1 |
| | 31682 | Chuck Nut Spanner | 1 |
| | 31692 | Chuck Body Spanner | 1 |
| | 6393 | Hexagon Key | 1 |

* Indicates normal replacement items. It is recommended that adequate stocks are held for servicing requirements.

Always quote tool number, serial number and spare part number when ordering spares.

SINGLE SPINDLE TAPPING HEAD

To Demantle

To remove the chuck (508) from the chuck spindle (523) first remove the retaining screw (501). Insert wedges either side of the chuck spindle, placing one side of the wedge on a bench. Tap the other side until the chuck slides clear.

Unscrew the three screws (556) enabling the spring housing (511), spring (512), thrust race housing (513) and the outer race (514) to be removed.

Unscrew the end cap (521) (L.H.) and remove complete with the chuck spindle and the sun pinion (522). To remove the sun pinion and the chuck spindle, tap the chuck spindle, springing off the cap and balls (515).

To remove the extension case (529) from the main AFD first place the AFD outer case between a pair of clamp blocks and mount in a vice. Remove the retaining screw (525), unscrew the extension case (L.H.).

To remove the reverse internal gear (524) from the driving dog (527) locate assembly tool (14963) into the reverse internal gear, and the flats on the driving dog in a vice and unscrew.

To remove the end cap wheel (517) unscrew the retaining screws (518) and push out the end cap pins.

To Assemble

With the retaining weather (506) and the retaining screw (525) fasten the driving dog to the AFD. Screw back the extension case on to the AFD (L.H.).

Using the assembly tool screw the reverse internal gear to the driving dog.

Replace the sun pinion and the chuck spindle into the end cap and press on the cap and balls.

Screw back the end cap on to the extension case, (L.H.), and replace items 510 to 514.

Tap on the chuck, making sure the chuck bore and the chuck spindle are clear of grease, and secure with screws.

AFD4
AFT40

Servicing Instructions

CONTROL TOP

To Dismantle

Unscrew and remove inlet adaptor (117), with any customer fitted connection. Unscrew and cap (127) exposing valve bush (123) and piston control valve (124). Using a thin wire hook pull out the valve bush with the piston control valve. Separate the valve from the bush and discard all 'O' rings.

The remainder of the dismantling is obvious with reference to the illustration. It is suggested that as each valve is removed it is placed in a container and identified for future use.

To Assemble

Assemble 'O' rings (126) to piston control valve then slide valve into the control valve bush (123). Fit 'O' rings (124) to valve bush and carefully fit the bush/valve assembly into the control top. Screw in and cap (127) and tighten to a torque of 10.8 to 13.5 Nm (8 to 10 lbf/ft).

Refer to the illustration for locating the remaining valves and components noting the following points:

Position a spring (107) on the spigot of each button assembly (112 & 115) and stroke control valve (122) before assembly into control top.

Tighten all valves and plugs to a torque of 8.5 to 9.0 Nm (75 to 80 lbf/in.).

Tighten inlet adaptor (117) to a torque of 31.0 to 38.0 Nm (23 to 27 lbf/ft).

Ensure that 'O' rings (101) are greased before placing in their housings in control top bore. Place assembled control top in an airtight container until required, see General Assembly for details.

MOTOR AND GEARBOX

To Dismantle

As the unit has already been partly dismantled, see General Assembly. It is only necessary to remove the piston (217) and lamp nut (201) then push the internal components out of the motor case (218).

The motor and gear train assemblies can be dismantled using normal workshop practice when removing bearings from spigots. Identify your gearbox in the illustration and refer to it for order of disassembly.

NOTE: Locknut (202) has a R.H. thread all other threads in this area are L.H.

To Assemble

The motor complete (218): Take the rotor (212) and place the rear bearing plate (210), with grooves to rotor, into position. Press bearing (209) onto the rotor so that there is a 0.038 mm (0.0015 in.) gap between the rotor and the rear bearing plate. Holding the rotor and rear bearing plate assembly with the gear end of the rotor uppermost, slide the cylinder (211) over the rotor.

Locate the rotor blades (213) into their slots in the rotor and lubricate. Place the front bearing plate (210) into position, with grooves to rotor.

NOTE: If a new bearing (209) is to be fitted into the front bearing housing (207) make sure that the bearing is 0.25 mm (0.01 in.) below the housing face out of which pin (206) protrudes.

Press the front bearing housing with its bearing onto the rotor making sure that all location holes are aligned so that the pins can pass through on assembly.

NOTE: This assembly should be pressed on using the inner face of front bearing (209) and taking the reaction on the end face of the rotor rear bearing spigot. The assembly should be pressed on until all the free axial movement between the front and rear bearings is removed.

Locate the rear bearing housing (214) with end cap (215) and check that the rotor is free to rotate.

The gear train: Refer to the illustration to identify the components in the gearbox and the order of assembly. Grease the bearings and gears on assembly and tighten locknut (203) to a torque of 8.4 to 9.0 Nm (75 to 80 lbf/in.).

NOTE: The piston (218) must be tightened onto the motor case (217) FIRST and final clamping carried out by fitting clamp nut (201).

TESTING AFTER ASSEMBLY

Required:

Hand Tachometer with a scale range to suit tool.

Dial Test Indicator (D.T.I.) on Stand.

Mandril - 61 mm (2 in) long by 6.5 mm (0.25 in) dia.

Spring Balance - capable of reading over 90 kg. (198.5 lbf.).

Operation Test

Fit clamp blocks to the tool and clamp in a vice with horizontally and control buttons uppermost. If used fit provide thrust resistance. Set a gap of 40 mm (1.5 in.) to stroke control valve and the stroke adjusting screw. In case drops of oil into the air inlet and connect up the airline.

Fully open the advance and retract regulating screws repeatedly press the green manual start button and cycle it a few times, checking that air pressure remains static.

Screw in the advance rate regulating screw to nearly. Press start button and at approximately mid stroke close advance rate regulating screw. Allow motor to attain its free speed, then using the tachometer check that the rpm within 5% of that stated on the tool label. On complete advance rate regulating screw and allow tool to complete spring balance to confirm.

Insert the mandril into the chuck and using the D.T.I. on the mandril (12.7 mm (0.5 in.) from check, check the 'out' does not exceed 0.15 mm (0.004 in.). If it is out of tolerance, lap side of chuck at high side to resettle it the

Reduce air pressure to 2.06 bar (30 lbf/in²). Press start and adjust advance rate regulating screw so that tool advances slowly and returns. Repeat test several times observing it and retract action is smooth and free from jerks. Test pin valve by alternatively pressing start button allowing tool slightly then pressing stop button to retract. Movement is smooth and without hesitation in each direction; when a stop tool in mid stroke by closing the advance rate regulating screw. Check for leaks by applying a film of oil around it and control buttons at their joints with the control top. Satisfied press the stop button and open the advance rate screw.

Disconnect the airline and remove tool from vice and it is now ready for use.

AFD40 AFT40

Operating/Service Instructions

SETTING DRILLING OPERATION

NOTE: This setting details a unit with a H.C.U., reference to the H.C.U. should be ignored when setting the standard tool.

Set the gap between the stroke control valve and the stroke adjusting screw to equal the depth of drilling required PLUS the distance the drill bit is above the work piece.

Unscrew the hydraulic stroke adjusting screw away from the H.C.U. and adjust the resistance within the H.C.U. to the minimum position.

Fully open the retract rate regulating screw.

Close the advance rate regulating screw.

Connect the air supply and press the manual start button.

Nothing will happen until the advance rate regulating screw is slowly opened, then the drill will gradually advance and approximately 8 mm (0.25 in.) from start of advance the drill bit will rotate.

Close the advance rate regulating screw approximately 1.0 mm (0.040 in.) before the stroke adjusting screw contacts the stroke control valve.

Set the hydraulic stroke adjusting screw to contact the H.C.U. and lock in position.

Unscrew the advance rate regulating screw; the tool will advance, under the control of the H.C.U. until the stroke control valve is contacted by the stroke adjusting screw at this point the tool will return to the start position and stop.

Carry out a set of trial drillings to determine the ideal advance and H.C.U. settings. Stalling on 'break-through' indicates that the H.C.U. is coming into operation too late or the advance rate is too fast.

SETTING TAPPING OPERATION

NOTE 1: It is important that the advance rate of the tool is set to match the pitch of the thread which it is to be tapped. An incorrect advance rate will result in a deformed thread, this will be more noticeable in plastics or light alloy materials.

2: The retract rate should be set to withdraw the tap at a slightly faster rate than it advanced, this will insure a clean withdrawal.

Mount the tool, with the selected tap securely retained in the chuck, above a test block to carry out sample tapping operations.

The end of the tap MUST be at least 14 mm (9/16 in.) above the test block, to allow for the tapping head reversing engagement travel. Set the gap between the adjusting screw and the retract

valve to equal the tapping depth PLUS the distance the tap is above the work piece.

Set the advance rate adjustment screw 1 turn open and the retract rate adjustment screw 1 1/2 turns open.

Carry out a trial tapping operation and inspect the finished thread form, adjust as necessary the advance/retract screws and repeat until information in NOTES 1 and 2 are satisfied.

SERVICING REQUIREMENTS

General Notes

Replace as necessary all 'O' rings, seals and bearings.

Use the following lubricants as indicated:-

Oil - ISO VG 15 or equivalent.

Grease - Rocol BRB1200 for bearings.

Grease - Duckhams Q5618 or equivalent.

Silicon Grease - Molykote 33, for 'O' rings.

The majority of threads in this tool are right hand (R.H.) but some left hand (L.H.) threads will be found. All L.H. threads will be noted in the text.

Servicing Tools

In addition to the normal range of workshop tools the following will be required:

| Description | Qty. |
|---------------------------------------|------|
| 75938 Wadges | 1 |
| 60073 Spanner for Bearing Sleeve (2) | 1 |
| 60053 Spanner for Motor Air Inlet Cap | 1 |
| 60113 Spanner for Clamp Nut (12) | 1 |
| 17943 Hexagonal Key 7/16 in | 1 |
| 59233 Gearcase Spanner | 1 |
| 60063 Spanner for Clamp Nut (201) | 1 |
| 60113 Spanner for Spindle Nut (202) | 1 |

Refer to the Parts Lists for illustrations and item references.

Cleaning

Required: Tank to immerse components.

Good quality clean paraffin.

Soak the components in the tank ensuring full immersion, agitate the component to ensure that any air passages are flushed through. After soaking, remove from the tank and thoroughly dry. Blow through any air passages to remove all moisture. Keep all cleaned components in an airtight container until required.

GENERAL ASSEMBLY

To Dismantle

Slacken crosshead clamping bolt (22) and remove assembly. Remove chuck or taper as fitted. Protect (16) and clamp in soft jawed vice, outer case horizontal spanner inserted in bearing sleeve (2), unscrew, under return spring (6) is under compression, outer case (4) top. Allow spring to expand slowly. Remove spring arm.

NOTE: It is recommended that bearing sleeve (2) protection cap be left on the outer case.

Check that air tube (21) is clear and pull motor assembly (5) complete with air tube from control top.

Hold the motor and gearbox and remove clamp nut thread. Remove felt ring (8). Remove spring pins (7) at motor and gearbox. Remove cap washer (3). From air clamping ring (10) and 'O' rings (9), discard 'O' rings.

Remove 'O' ring (13) from adaptor (14) and hence discard 'O' ring. Remove and discard 'O' ring (15).

NOTE: Dismantling the control top and the motor assembly are detailed later in the text.

To Assemble

Fit new 'O' rings (9) to air tube (21). Enter air tube piston of the motor gearbox (5) with clamp ring (10) in of the piston. Assemble clamp ring (10) to the air tube onto its seat in the piston. Secure in position with spirit Fit new felt ring (8) to piston. Assemble piston seal (1) nut (12), slide assembly over the air tube and secure to Fit new 'O' ring (15) to the control top (16) and fit adaptor control top in a soft jawed vice, hold motor and gearbox and carefully enter air tube through the control top into by clamp nut. Grease return spring (6) and insert into a Fit new 'O' ring (13) to adaptor (14). Slide outer case over motor and gearbox. Hold outer case and again compression, engage case thread and screw up as far as hand. Finally tighten with 'C' spanner inserted in bearing. Remove the assembly from the vice.

Assemble the crosshead assembly onto the air tube using the clamping screw (22).

Refer to the Operation Instructions for setting up an After Assembly and test the tool as detailed.

AFD4 AFT40

REQUIREMENTS

Air Supply - Main

A water free and filtered air supply is required, at a pressure of 6 bar (87 lbf/in²), with a flow of 9.4 l/s (120 cu.ft/min); controlled by a pressure regulator selected from the Desoutter Air Line Services Equipment Catalogue.

Air Supply - Remote

The basic requirements are as above but the pressure must be at least 2.7 bar (40 lbf/in²) and the flow requirement when signalling is 0.47 l/s (11 cu.ft/min). The signal duration should be kept to the minimum to reduce air consumption.

Lubrication

Correct lubrication is vital for the maximum performance of the tool and an airline lubricator should be fitted into the system down stream of the filter.

Desoutter recommend the use of an ISO Viscosity Classified Oil, grade number ISO VG 15, in the lubricator.

Accessories

GUARDS: IT IS RECOMMENDED THAT SUITABLE GUARDS ARE SELECTED, FOR CHUCK AND CONTROL TOP LOCATION, FROM THE DESOUTTER ACCESSORIES CATALOGUE.

Mounting Clamps: A range of clamps, bases and columns are available. Full details obtained from Desoutter.

Hydraulic Check Unit (H.C.U.): The tool will function satisfactorily, when drilling a blind hole at the set feed rate. Should it be required to break through the material and possibly through into another hole, feed acceleration will occur with possible drill breakage. To obviate this, the fitting of an H.C.U. is strongly recommended. Request information from Desoutter.

Peck Feed Kits: The Desoutter Peck Feed Drill System should be used when the depth of the hole to be drilled is five or more times the hole diameter. This helps clear drill chips and avoids excessive overheating of drill bit. Hole size accuracy can be improved and drill bit run-out can be kept to the minimum. Request information from Desoutter.

Multi-spindle Drilling and Tapping Attachments: A series of 2, 3, 4 and 5 spindle drilling and tapping heads are available. Full details available from Desoutter.

Operating Instructions

OPERATING

Control Top

The control top (1) contains all the control functions and signal orignations for external control.

The controls and locations are identified below and detailed in the Drilling Operation.

Location 2: 'P' port tapped M5, signal point for peck feed circuit.

3: 'O' port tapped 1/8in. BSP, receives external signal to return the feed to start position.

4: Stroke Control Valve.

5: 'M' port tapped M5, signal produced when the motor is running, used for sequence control. By ensuring this signal it can be determined that the drilling cycle has commenced/finished.

6: 'T' port tapped 1/8in. BSP, receives external signal to start the tool cycle.

7: Main air inlet port, topped 1/8in. or 1/2in. BSP or NPT.

8: Manual Start Button - Green.

9: Manual Stop Button - Red.

10: Advance Rate Regulating Screw.

11: Retract Rate Regulating Screw (Tapper only).

NOTE: The 'M' port is intended for the operation of pilot valves. It must not be used as a source of air supply for other uses.

Mounting the Tool

The tool must be clamped only in the area indicated on the outer case.

The drill must be at least 6 mm (0.25in.) above the work piece.

WARNING: (1) ALWAYS DISCONNECT TOOL FROM THE POWER SUPPLY BEFORE ATTEMPTING ANY REPLACEMENT, ADJUSTMENT, SERVICING OR DISMANTLING.

(2) ENSURE THAT NO LOOSE ARTICLES OF CLOTHING OR CLEANING MATERIAL CAN BE CAUGHT BY THE ROTATING PARTS OF THE TOOL.

(3) ALWAYS ALLOW THE TOOL TO STOP BEFORE REMOVING WORK OR RESTING TOOL.

(4) ENSURE THAT WORK PIECE IS SECURELY CLAMPED BEFORE COMMENCEMENT OF OPERATION - CLEAR ALL LOOSE ITEMS FROM VICINITY.

