



Automation Screwdriver Accessories





Desouller


Screwdriver Automation Accessories

Spring Loaded Shafts



Adaptor 1/4" hex power to Ø10mm

Each spring loaded shaft features 25mm of travel and a 3/8" square drive. The adaptor allows the shaft to be fitted to the screwdriver and drives through a key. The adaptor is retained by a screw.




103782

Nose Mounts



Nose mounts allow the screwdriver to be mounted squarely on a plate. The mounts are designed to fit on the clutch case thread.


Description	Part No.
SC Series – ³ / ₄ " x 26 TPI LH	103722
D Series – 7/8" x 26 TPI LH	103732
SB Series – M20 x 1.0 LH	108392



Combined Spring Loaded Shafts with Bearing Support and Nose Mounts



The bearing support includes a needle roller bearing to support the shaft to maintain alignment and also provides a mounting location for the screwdriver into a plate. The shaft has a ground finish for accuracy of location.




Part No.

108322

Bit Adaptor



Description 3/8" Square to 1/4" hex power For use with 108352 and 108342 spring loaded shafts, the bit adaptor is held on the square drive with a pin and o ring. A guide pin which screws into the shaft ensures that the adaptor is held in line with the spindle.



Offset Head



For use with the SC and D series tools (a thread adaptor is supplied with the head), the offset head allows the assembly of fasteners on close centres (minimum 19mm).

